

STDS851-SA Installation on a Bellavita

1. Slide end of STDS851-SA through bottom back slot of the back rest.

2. Press the loop & hook Velcro together.

